



Tyrrell & Laing
INTERNATIONAL INC.

Installation Instructions for Slotted Drains



1. Apply plumber's putty to the bottom of the top plate of the drain piece.
2. Insert the slotted drain into the drain opening.
3. Place the silicone gasket over the drain on the bottom of the bathtub.
4. Start the nut on the end of the drain and hand tighten the nut to the silicone seal.
5. The "Slot: in the drain will pick up the overflow water and evacuate it in the drain.

Please ensure you follow the plumbing specifications for a problem free installation:

1. Measure and mark where you would like the bathtub to be placed in the room.
2. Note that the waste is exactly in the center of where the tub will be.
- 3. After completion of installation, it is imperative to silicone the base of the bathtub to the floor.**
4. To protect the bathtub, we suggest leaving the bubble wrap on the tub until all work is finished and all trades have left the room.

***DO NOT TIGHTEN DRAIN USING LIFT AND TURN MECHANISM. THIS WILL BREAK THE DRAIN.**