

## How to open crate:

1. Screws that need to be loosened will be marked with spray paint. There are 3-4 screws in 5 areas along the bottom of each long side of the crate (see *photo on right*).
2. Using a drill, loosen screws so that they are not penetrating both layers of wood and the protection top may be lifted off, but do not take them off completely (see *photos on right*).
3. Do this on both long sides of the crate.
4. Have a person on each side of the crate to lift the protection top, holding it from the bottom (see *photo on right*).
5. Lift the protection top straight up, as to not damage the contents of the crate. Remove the protection top once it is lifted higher than the height of the contents (see *photo on right*).

